



## Quiver Critter v13.1 #20513-6

Thank you for purchasing a Lucy Duck™ Premium Decoy.

To view additional Lucky Duck™ products please visit your local Sporting Goods dealer or log on to our website at [www.luckyduck.com](http://www.luckyduck.com).

1. To install (2)-AA batteries (not included) in the provided battery compartment, first unscrew the cover on the puck shaped quiver body.

**DO NOT MIX OLD & NEW BATTERIES. DO NOT MIX ALKALINE, STANDARD (carbon zinc) or RECHARGEABLE (ni-cad, ni-mh, etc) BATTERIES.**

2. Install the (2)-AA batteries with the negative contact against the spring.
3. Rotate the battery securing arms over each battery until they snap to keep the batteries in place while the unit is running.
4. Replace the screw on cover.
5. Thread the metal stake into the bottom of the cup. Insert the stake into the ground as vertical as possible. The thread on the Quiver Critter cup has been designed to fit most tripods. For rocky or frozen ground situations it is advisable to use a small tripod.
6. Place the head of the silver screw with the rubber coating inside the hole on top of the cup.
7. There should be approximately 1/8" gap between the top of the cup and the bottom of the puck once it has been installed.
8. Lift the bottom of the decoy sock to expose the rubber ON/OFF switch. Press to turn on/off.

### Troubleshooting:

If your Quiver Critter does not start to quiver when you turn the unit on, be sure it is upright when you press the power button. There is a heavy counter weight inside that the motor can not turn when on its side. If that is not the problem, check to see if you have fresh batteries and that they are installed correctly.

You can create more or less motion by adjusting the offset between the cup top and the quiver body bottom by adjusting how far the screw on the bottom of the quiver body is threaded in. The Quiver Critter wire needs to be aligned vertically to get the most action.

**Warranty:** Lucky Duck™ warrants this product against all manufacturing defects for a period of 1 year from date of purchase. Proof of purchase is required. Abuse of the product (submerged in water, dropped, mistreatment etc.) is not covered. Please return and exchange the defective unit to the store where you purchased the product. If the store will not accept the return, please call our customer service phone number at 715-338-3183.



Lucky Duck™  
A Division of Expedite International, Inc.  
1950 8<sup>th</sup> Ave.  
Baldwin, WI 54002  
Customer Service: 715-338-3183  
[www.luckyduck.com](http://www.luckyduck.com)